



WaveWare Technologies, Inc.

"We Deliver Information at the Speed of Light"



WaveWare Software PC Requirements

Desktop PC Requirements:

The Minimum Hardware Requirements for use with WaveWare Software are:

Desktop PC Model with...

Windows XP Pro SP3 or Windows 7 Pro SP1

1+ GHz Processor

10+ GB Hard Drive

2+ GB Memory

1+ RS-232 Serial Com Ports*

1 Ethernet Port

1 CD-ROM

(Only for Installing Software from a CD)

* More RS-232 Serial Com Ports may be needed depending on the Application Requirements

WaveWare **ONLY** Supports **Desktop** Model PC's

WaveWare Does **NOT** Support Windows 8, PC Terminals, Tablets or Virtual Machines (PC's)

WaveWare Does **NOT** Support Real Servers PC's or Server OS's

No Virtual Ports of any Type are Supported

Software Application Requirements

Alert Utility: Requires a Minimum Qty of **3** RS-232 Serial Com Ports

Call Manager: Requires a Minimum Qty of **3** RS-232 Serial Com Ports

Enterprise Messaging: Software Requires a Minimum Qty of **1** RS-232 Serial Com Port

WaveWare Technical Support: Support@WirelessMessaging.com or 1.800.373.1466 x216

Software Developed by WaveWare Technologies, Inc.

Copyright © 2014