


WaveWare SPS-5 v9E (Ethernet and Serial) Basic Installation Diagram

The SPS-5 v9E can be used with Qty 3 Host Systems. The Ethernet Port can have 2 Hosts attached to it by using 2 Socket Connections on 1 IP Address and another Host attached to the RS-232 Serial Com Port.



TITLE		DWN BY Bob Clyburn	
SPS-5 v9E Paging System Basic Installation Diagram		DATE 5.20.14	
WAVEWARE TECHNOLOGIES, INC. Garland, Texas USA 972-479-1702	DWG. NUMBER	REV. 1	