


Ethernet Serial Servers with SPS-5 Paging System Attached to the Host System



Send a Paging Message to a the Assigned IP Address of the Ethernet Serial Adaptor attached to the Paging System.

WaveWare **Alert Utility** Software may be Required to help this happen.

MATERIAL	FINISH None	DATE 7.9.12
TITLE SPS-5 Series with Ethernet Serial Server Installation Diagram		DWN BY Bob Clyburn
		APP.
WAVEWARE TECHNOLOGIES Garland, Texas 972-479-1702	DWG. NUMBER	REV. 1