

**AS Series LED Sign without Relay Configuration – Pre-Configured as Shown – Over-the-Air-Commands**

* Calculated Value or See Manual or Note: Frequency, Cap Codes and Baud Rate -	Check Notes at Bottom of Page for a Quick Reference Are Programmed using Software		Commands are Sent by way of Paging
ITEM	NOTES	DEFAULT	OTA COMMAND
Sign Type *	Choose 1 or 2 Line (First OTA Command)	2	GALEDTYPE=2
Buzzer On/Off *	Default is Usually Turned ON	ON	GALEDBZ=ON
Buzzer On Time *	1 Second	001	GALEDBZTM=001
Buzzer Music Type *	Type 0 = Solid Tone	0	GALEDBZTY=0
Default Message	Blank (Unless Specified by Customer)		GALEDMESG=***
Message Counter *	Automatic	AU	GALEDMGCT=AU
Auto Clear Delay Time *	5 Minutes (Unless Specified by Customer)	300	GALEDCLRDY=300
Auto Clear Count Times *	Normally NOT Used (Unless Specified by Customer)	000	GALEDCLRCT=000
Clear by Reset *	RESET (Prefix or Suffix with Space Between)	ON	GALEDRESCM=ON
Clear by Cancel *	CANCEL (Prefix or Suffix with Space Between)	ON	GALEDCANCM=ON
Time Stamp Mode *	0=OFF (Default is Usually - NOT Used)	0	GALEDTMSM=0
Appear Message Mode *	Hold	7	GALEDAPPM=7
Disappear Message Mode *	Instant	A	GALEDDISM=A
Delete All Messages	Deletes Every Message on the Sign		GALEDDELALL

**AS Series LED Sign with Relay – Add this Configuration – Pre-Configured as Shown – Over-the-Air-Commands**

Priority Msg Cap Code(s) *	Specified by Customer - Normally all ON (FFFFFF)	FFFFFF	GALEDPRICAP=FFFFFF**
Priority Message *	Support Both Priority Msg and Priority Msg Cap Code	4	GALEDPRIM=4
Priority Msg Relay “ON” Time *	10 Seconds (How Long the Relay will Stay Active)	010	GALEDRLYTM=010
Priority Message Counter *	1 to 5 (Default 5)	5	GALEDPRICT=5
Priority Message Clear *	Support Clear Command (Normally ON)	ON	GALEDPRICLR=ON
Automatic Message Counter *	1 to 24 (Default 24)	24	GALEDAUCT=24
Priority Msg Auto Clear Delay Time *	3 Minutes (Unless Specified by Customer)	180	GALEDPCLRDY=180

**Date and Time - Normally Not used – Add this Configuration – Pre-Configured as Shown – Over-the-Air-Commands**

Timer Display *	Default is Usually - Turned Off	OFF	GALEDTM=OFF****
Timer Date On/Off *	Default is Usually - Turned Off	OFF	GALEDDT=OFF****
Timer Date Setting *	Default is Usually - NOT Used		GALEDDATE=YYMMDD
Timer Date Mode	MM, DD, YY (Default is Usually - NOT Used)	1	GALEDDTMD=1
Timer Time Setting *	24 hr Clock (Set Only when Timer is Active)		GALEDTIME=HHmmSS
Timer Month Language	English (Set Only when Timer is Active)	ENG	GALEDLANG=ENG

\*\* Priority Cap Codes: 0= Non-Priority and F= Priority (For each Cap Code Slot, 6 Total). For Instance: If Cap Code 1, 3 and 5 are Priority and 2, 4 and 6 are not Priority then the OTA Command would look like this: GALEDPICAP=F0F0F0  
 \*\*\* This is the Message that will Show when No other Messages are being Displayed on the Sign, for NO Message, Send Nothing at all.  
 Note: A 911 Prefix is used for Non-Priority Cap Codes and a “Priority Message” has to be sent in order for the Relay to work, if the Relay is Activated.  
 Any Command sent must have No Spaces in order to work. \*\*\*\* If “OFF” Send “ON” instead to Turn ON that Feature.